



PARTS LIST

1	40 W/M HEATING CABLE
2	INSULATED ENCLOSURE
3	CONTROL BOX

TRACE HEATING

A CONTINUOUS LOOP OF TRACE HEATING CABLE IS ATTACHED TO THE REAR GUARD TUBE OF THE INDICATOR. THE CABLE IS TERMINATED AT ONE END TO A CONTROL BOX WHICH CAN BE USED TO REGULATE THE TEMPERATURE IN THE INDICATOR VIA A TEMPERATURE PROBE.

CONTROL BOX

VOLTAGE SUPPLY 220-240V
WITH TEMPERATURE DISPLAY AND PROBE.

EXAMPLE

AMBIENT AIR TEMPERATURE = 20°C
50°C - 60°C LIQUID TEMPERATURE IN INDICATOR MAXIMUM.



SEETRU LIMITED

ALBION DOCKSIDE WORKS, BRISTOL. BS1 6UT
TELEPHONE +44 (0) 117 927 9204, FAX +44 (0) 117 929 8193
www.seetru.com enquires@seetru.com

MAGNETIC LIQUID LEVEL INDICATOR
WITH TRACE HEATING

SEEMAG G35

SHEET 3 OF 6 SHEETS